



BS Meter Terminal Arrangement




DIN Meter Terminal Arrangement

Figure 5 - Terminal Arrangements


BS without auxiliary connection



BS with relay output option



DIN with relay output option



Note: These diagrams are examples only.



WARNING

Meters must be connected according to the diagram fitted under the meter terminal cover.

Figure 5A – Terminal Configurations